

Troubleshooting

Problem	Solution
Glow Rollers will not light up.	Ensure the switch is in the "ON" position.
Glow Rollers are flashing red.	The batteries are running low and need recharging in the docking station.
Glow Rollers are not changing colour.	Check the Glow Roller is turned on the correct side.



EY07202 Glow Rollers

Quick Start Guide

TTS is proud to be part of **RM** plc



TTS Group Ltd., Park Lane Business Park,
Kirkby-in-Ashfield, Nottinghamshire, UK NG17 9GU

www.ttsgroupsupport.com

Important Information

Please retain the information in this User Guide for future reference.

Please read all instructions fully before using.

To clean, wipe the surface with a clean damp cloth.

Do not allow the product to come into contact with water or other liquids.

Keep the product away from direct sunlight and heat.

If your product malfunctions please switch it off and then back on again to reset it.

Battery Precautions

Glow Rollers are powered by lithium battery packs which are not user replaceable.


Do not attempt to remove the battery packs.

This product comes with a 5V 1A adaptor.

Contents of Pack

- 6 x Glow Rollers
- Docking Station
- International Charging Adaptor
- User guide

Know Your Glow Rollers



Using Your Glow Rollers

To switch the Glow Rollers on, move the slide switch to the ON position.

When the Glow Roller is positioned with the On/Off switch at the bottom or the Glow Roller positioned horizontally the lights will cycle through seven different colours. When the Glow Roller is turned with the On/Off switch facing upwards the lights will stay on the current colour at point of turn.

Always switch your Glow Rollers off when not in use to preserve the battery life.

Recharging Your Batteries

Insert the adaptor cable into the charging socket at side of the docking station.

Plug the adaptor into a wall socket.

Place the Glow Rollers into the docking station ensuring they are fully connected.

It may take up to 4 hours to fully charge if the battery has been fully discharged.

The Glow Rollers will flash red to show that the batteries are low and the product needs charging.

The Glow Rollers will light solid red when charging.

The Glow Rollers will light solid green when fully charged.

Only charge your Glow Rollers in the docking station and only use the battery charger provided.

It is not possible to operate the toy during charging.

The charger must be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until that damage has been repaired.

International Power Supply

The Glow Rollers docking station is supplied with a multi-region power supply which is supplied with the UK plug fitted. This can easily be changed to suit any country. Press the release button to release the UK plug and replace with the required plug module. Ensure that the plug clicks in place securely.